QUOIZEL.

Installation Guide For Style TF6669VB

 $Please go to {\color{red} www.quoizel.com} for product cleaning tips. Go to the {\color{red} Care+Maintenance} selection.$

Tools Required: None.

Bulb Recommended: (2)A19 Medium Base Bulbs 60W Maximum, bulbs not included.

Estimated Assembly Time: 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact your original place of purchase.

A Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

△ Care of Tiffany Style Shade

A new tiffany lamp shade has an oil film applied to the shade that protects the tiffany shade from scratches during shipment. If the oil applied is too heavy you can remove the excess oil film with a paper towel. Gently wipe away the excess oil.

For general cleaning of tiffany shades use a gentle lemon oil-based furniture polish applied to a soft cloth and wipe gently.

If a white powder appears on the soldered joints of the tiffany shade this is a normal oxidation process. Use a small amount of lemon oil or mineral oil applied directly to oxidized areas and the soldered area will return to like new.

- A. Thread the hex nut end of Nipple w/ Hex Nut into hex coupling on the top center of the base. By using pliers, thread the hex nut against the hex coupling and hand tighten until snug.
- B. Place the Spacer Tube and the Check Ring over the Nipple. Secure by thread the Small Knurled Nut onto the Nipple. Hand tighten until snug.
- C. Thread the Big Knurled Nut onto Nipple. Place the Flat Washer and the Shade over the Nipple. Adjust the Big Knurled Nut to proper location for the Shade and Finial. Thread the Finial onto the Nipple to secure the Shade. Hand tighten until snug.
- D. Insert bulbs onto sockets and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!

