

## TT80096 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

## CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

## GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## **ASSEMBLY AND INSTALLATION**

- 1. Attach the rods (1) to the wiring house(2).
- 2. Put the shade (3) over the socket, secure it with the socket ring(4).
- 3. Install the bulb (5, not included) into the socket.

Do not exceed suggested maximum wattage - Max.60W

DO NOT USE BARE HAND TO TOUCH THE BULB.

INSTALLATION IS NOW COMPLETE

