

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102 P: 866-845-5451 • F: 866-816-6165 E: service@acclaim-lighting.com • www.acclaim-lighting.com

Item No . TF7305 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1. Place the lamp body (8) on the floor.

2. Squeeze legs of harp (4) together and insert the two ends between the prongs of the harp holder (6).

3. Place shade (3) and rubber washer (2) over harp (4) and secure with finial (1).

4. Install a 150 watt maximum medium base 3-way bulb (not included) into socket.

INSTALLATION IS NOW COMPLETED

