

ASSEMBLY INSTRUCTION FOR L313850

1. FASTEN SOCKET ASSEMBLY ONTO BASE, BE CAREFUL NOT TO TWIST POWER CORD AND TIGHTEN SECURELY.
2. SCREW BULB INTO SOCKET, BULB (MAX 3-WAY 150W) NOT INCLUDED.
3. PLACE HARP ONTO SADDLE.
4. PLACE SHADE ONTO HARP AND TIGHTEN FINIAL.

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LUMINAIRE HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

