IN10015WG INSTALLATION INSTRUCTIONS

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102 Phone: (866) 845-5451. Fax: (866) 816-6165 www.acclaim-lighting.com



Please read carefully and save these instructions as you may need them a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

- 1. Thread the Loop onto the Coupling at the top of the fixture body.
- 2. Attach the cross bar (with nipple, washer, hex nut and top loop) to the outlet box using the 2 mounting screws.
- 3. Use two quick links at the ends of the chain to link the fixture loop and chain, then the chain to the top loop.
- 4. Lower the canopy onto the top nut and pass the top loop through canopy.
- 5. Make wire connections:
 - ---The ridged wire (unmarked) from the fixture to white wire from power source.
 - ---The smooth wire (marked) from the fixture to black wire from power source.
 - ---Attach the ground wire to cross bar with a green screw.
- 6. Place the canopy over the outlet box and secure the canopy with top nut.
- 7. Install bulbs: (Bulbs not included). (Don't exceed the maximum capacity recommended on the sockets).

OUTLET BOX BLACK WIRE WHITE WIRE WIRE CONNECTOR WIRE CONNECTOR CROSS BAR **GROUND WIRE** MOUNTING SCREW WASHER **GROUND SCREW** HEX NUT -NIPPLE - CANOPY TOP LOOP TOP NUT WIRE QUICK LINK CHAIN QUICK LINK -LOOP COUPLING -BULB -SOCKET

INSTALLATION IS NOW COMPLETED.